


# How do I hide or disable the image to the projector?

## Tell Me

Sometimes you may need to hide your screen from displaying on the projector screen while you work on the monitor. Instead of turning off the projector, you can use the Mute Video function to quickly disable and re-enable the image.

1. To disable the image feed to the projector, press the **Mute Video** button on the right side of home page of the touch panel.



2. To re-enable the image feed to the projector, press the **Mute Video** button again.

 The Mute Video function works with any source.

## Related FAQs

- [How do I connect a laptop to the smart podium using HDMI?](#)
- [What does the System Help button do?](#)
- [How do I use the podium microphone?](#)
- [How do I shut down the smart podium system using the touch panel?](#)
- [How do I select a source using the touch panel?](#)